

Option Adaptor for FWD series

Operating Instructions

Mode d'emploi

Bedienungsanleitung

Manual de instrucciones

Istruzioni per l'uso

取扱説明書

使用说明书

お買い上げいただきありがとうございます。



安全のための注意事項を守らないと、感電やその他の事故によりけがをしたり周辺の物品に損害を与えたりすることがあります。

この取扱説明書をよくお読みのうえ、製品を安全にお使いください。
お読みになったあとは、いつでも見られるところに必ず保管してください。

BKM-FW10/FW11/FW12

© 2004 Sony Corporation Printed in Japan

English

WARNING

Owner's Record

The model and serial numbers are located on the rear.
Record the model and serial numbers in the spaces provided below. Refer to these numbers whenever you call upon your Sony dealer regarding this product.

Model No. _____ Serial No. _____

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

Do not open the cabinet.
Refer servicing to qualified personnel only.

For installation, consult your nearest Sony dealer.

For customers in the U.S.A.

If you have any questions about this product, you may call;
Sony Customer Information Services Center
1-800-222-7669 or <http://www.sony.com/>

Declaration of Conformity

Trade Name : SONY
Model : BKM-FW10/FW11/FW12
Responsible Party : Sony Electronics Inc.
Address : 16450 W. Bernardo Dr,
San Diego, CA 92127 U.S.A.
Telephone Number : 858-942-2230

This device complies with part 15 of the FCC rules.
Operation is subject to the following two conditions: (1)
This device may not cause harmful interference, and (2) this
device must accept any Interference received, including
interference that may cause undesired operation.

For BKM-FW11 Users

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

These Option Adaptors are for the FWD series Sony Flat Panel Display. You can install any of these adaptors in your display.

For details on how to operate the Option Adaptor, refer to the Operating Instructions for the display.

For details on installation, contact your authorized Sony dealer.

Français

AVERTISSEMENT

Pour prévenir tout risque d'incendie ou d'électrcution, garder cet appareil à l'abri de la pluie et de l'humidité.

N'ouvrez pas le châssis.
Confiez-en l'entretien exclusivement à un personnel qualifié.

Pour l'installation, consultez votre revendeur Sony.

Ces adaptateurs en option sont conçus pour les moniteurs à écran plat de la gamme FWD de Sony. Vous pouvez installer n'importe lequel de ces adaptateurs sur le moniteur. Pour plus de détails sur l'utilisation de l'adaptateur en option, reportez-vous au Mode d'emploi du moniteur.

Pour plus de détails sur l'installation, consultez votre revendeur Sony agréé.

Deutsch

VORSICHT

Um Feuergefahr und die Gefahr eines elektrischen Schlags zu vermeiden, darf das Gerät weder Regen noch Feuchtigkeit ausgesetzt werden.

Öffnen Sie daher das Gehäuse nicht.
Überlassen Sie Wartungsarbeiten stets nur qualifiziertem Fachpersonal.

Wenden Sie sich zur Installation bitte an Ihren Sony-Händler.

Diese Zusatzadapter sind für Flachbildschirme der Serie FWD von Sony gedacht. Sie können jeden dieser Adapter im Bildschirm installieren. Erläuterungen zur Verwendung eines Zusatzadapters finden Sie in der Bedienungsanleitung zum Bildschirm.

Einzelheiten zum Installieren erfahren Sie bei Ihrem autorisierten Sony-Händler.

